

# Using the Verizon Jetpack Hot Spot




## Using the Hot Spot














The Power button serves as showing all of the menu items. Cycling through the menu will give you the following options:

- 1<sup>st</sup> press shows data usage information.
- 2<sup>nd</sup> press shows the WiFi name.
- 3<sup>rd</sup> press shows the Password.
- 5<sup>th</sup> press takes you back to the main home screen.

## Connecting your device to the Hot Spot

- 1) Press and hold the Power button until the Jetpack turns on.
- 2) On the device that you want to connect, open the WiFi app or settings and select APTS Hotspot\_x (x signifies a number on your hotspot) from the list of available networks
- 3) Select Connect
- 4) When prompted, enter the WiFi password APTS2020p

Charging Indicator Light		
	Colors	Charging Status
	Off	The Jetpack is not connected to a charger.
	Red	The Jetpack is connected to a charger and is currently charging.
	Green	The Jetpack is connected to a charger and the battery is fully charged.

Display Icon	
ICON	DESCRIPTION
 Network Signal Strength	Shows network signal strength. 
 Activity Indicator	Appears when data is being transferred between the mobile network and your Jetpack. 
 Connected Devices	Shows the number of connected devices. When the Jetpack can't support any more devices, MAX is shown. 
 Roaming Indicator	Appears when your Jetpack is roaming.
 Messages	Appears when you have unread text messages. 
 Battery Charge Indicator	Shows the battery charge status. 
 Charging	Appears when battery is charging.
 SIM Indicator	Appears when your Jetpack needs to notify SIM status. 